

Organ Specifications

(numbers refer to stopknobs and coupler tabs)

GREAT <i>(II)</i>			SWELL <i>(III)</i>		
17	16'	Violone	7	16'	Lieblich Gedeckt
11	8'	Principal	13	8'	Geigen
6	8'	Spitzflöte	6	8'	Hohlflöte
10	8'	Bourdon	12	8'	Holzgedeckt
5	8'	Salicional	19	8'	Spitz Gambe
16	4'	Octave	18	8'	Spitz Celeste
9	4'	Nachthorn	25	8'	Flauto Dolce
4	4'	Flûte à Fuseau	24	8'	Flute Celeste (t.c.)
15	2 2/3'	Octave Quint	5	4'	Octave Geigen
14	2'	Super Octave	11	4'	Rohrflöte
8	2'	Waldflöte	23	2 2/3'	Rohr Nasat
3		Cornet IV-VI	4	2'	Flageolet
13		Fourniture V	17	1'	Siffflöte
7		Scharf III	10		Plein Jeu V
2	8'	Trumpet	16		Cymbal III
12		Chimes (solo)	3	16'	Basson
1		Great Unison Off	9	8'	Trompette
			2	8'	Cornoepen
			22	8'	Hautbois
		<u>SANCTUARY PITCH</u>	21	8'	Vox Humana
			15	4'	Clarion
2	8'	Spitzflöte	20		Tremulant
1	4'	Prestant	1		Swell 16'
			8		Swell Unison Off
			14		Swell 4'
		<u>CHOIR <i>(I)</i></u>			
21	16'	Gemshorn (ext)			
20	8'	Montre			<u>POSITIV <i>(floating)</i></u>
5	8'	Viola			
4	8'	Viola Celeste	11	8'	Suavial
10	8'	Gemshorn	6	8'	Nason Flute
9	8'	Gemshorn Celeste (t.c.)	8	4'	Prinzpal
15	8'	Gedeckt	3	4'	Rohrflöte
19	4'	Prestant	5	2'	Oktav
14	4'	Koppelflöte	10	1 1/3'	Quint
13	2 2/3'	Nasard	2		Sesquialtera II

12	2'	Blockflöte		7		Scharf IV
8	1 3/5'	Tierce		4		Zimbel III
18		Mixture III		9	8'	Regal
3	16'	Ranket		1		Tremulant
2	8'	Krummhorn				
7	4'	Rohr Schalmel				
17		Harp				<u>SOLO-BOMBARDE(IV)</u>
1		Tremulant				
6		Choir 16'		14	8'	Orchestral Flute
11		Choir Unison Off		7	8'	Violoncello
4		Choir 4'		6	8'	Cello Celeste
				13	4'	Octave
				12		Grand Chorus VI
		<u>PEDAL</u>		5	8'	French Horn
				4	8'	Cor Anglais
12	32'	Sub Principal (ext)		11	8'	Bombarde
24	32'	Contra Bourdon (ext)		10	4'	Bombarde Clarion
6	16'	Contra Bass		1		Tremulant
11	16'	Principal		3	8'	Trompette Harmonique
5	16'	Bourdon				(unenclosed, 25")
18	16'	Violone (gt)		9		Solo 16'
23	16'	Gedeckt (sw)		2		Solo Unison Off
17	16'	Gemshorn (ch)		8		Solo 4'
4	8'	Principal				
16	8'	Bourdon (ext)				
10	8'	Spitzflöte				<u>COUPLERS</u>
22	8'	Gedackt (sw)				
9	4'	Choral Bass		1		Gt/Ped
21	4'	Blockflöte		2		Sw/Ped
15	2'	Flöte (ext)		3		Sw/Ped 4'
3		Furniture V		4		Ch/Ped
2	32'	Contre Bombarde (ext)		5		Ch/Ped 4'
1	16'	Bombarde		6		So/Ped
8	16'	Basson (sw)		7		Pos/Ped
14	16'	Rankett (ch)		8		So/Sw
7	8'	Trompette		9		Ch/Sw
20	8'	Basson (sw)		10		Pos/Sw
13	4'	Clarion (ext)		11		Sw/Ch 16'
19	4'	Schalmel		12		Sw/Ch

			13	Sw/Ch 4'
			14	Gt/Ch
			15	So/Ch 16'
			16	So/Ch
			17	So/Ch 4'
			18	Pos/Ch
			19	Sw/Gt 16'
			20	Sw/Gt
			21	Sw/Gt 4'
			22	Ch/Gt 16'
			23	Ch/Gt
			24	Ch/Gt 4'
			25	So/Gt 16'
			26	So/Gt
			27	So/Gt 4'
			28	Pos/Gt
			29	Sw/So
			30	Gt/So

